

T10

## WYE - DELTA STARTING USEABLE ON 2,4 AND 6 POLE MOTORS.



REFER TO THE WYE-DELTA STARTER CONNECTION INSTRUCTIONS FOR PROPER CONNECTION OF POWER LINES TO STARTER.



REFER TO THE CUTLER — HAMMER OR EQUIV. FOR PROPER SELECTION OF OVERLOAD HEATER COILS.

				UNLES	ERANCES S SPECIFIED				<b>ELECTRIC</b>	MOT	TORS	DRAWN	WLW 09/08,	/77
				DEC.	INCHES		3	<b>(•)</b>	GEARM			СНК	RPB 09/12/7	7
				.x	±.1	I.			AND [	DRIVE	ES	APPD	JCW 09/12/	77
03	REV'D LOW VOLTAGE CONN. LEADS PER ELEC.	BJB 06/07/00		.xx	±.01	TITLE	DELTA -	WYE	CONNECTION	DIA	GRAM	SCALE	1=1	
02	ADDED T-STAT. NOTES PER ELECTRICAL	KMM 06/02/98		.xxx	±.005							REF		
01	REDRAWN TO CAD	DBT 06/02/97		.xxxx	±.0005	MAT'L.						FMF		
NO.	REVISION	BY & DATE	снк	ANG	±1/2°	FINISH						PREV		
	THIS DRAWING IN DESIGN AND DETAIL IS OUR PROPERTY AND MUST NOT BE	RFP			CAD FILE	. 0	0417201		SIZE	DRAWING NO		1	REV.	
	IN CONNECTION WITH OUR WORK ALL RIGHTS OF DESIGN AND INVENTION / THIS IS AN ELECTRONICALLY GENERATED DOCUMENT - DO NOT SCALE	DIST					Α	004	<u> 172-</u>	-01 (	03			

LINE LEADS

ROTATION CAN BE REVERSED BY INTERCHANGING ANY TWO LINE LEADS

• RED LEADS OR P1, P2, FOR N/C THERMOSTAT

ACROSS THE LINE START & RUN										
	LINE 1	LINE 2	LINE 3	JOIN & INSULATE SEPARATELY						
HIGH VOLT	T1,T12	T2,T10	T3,T11	(T4,T7) (T6,T9)	(T5,T8)					
LOW VOLT	T1,T6 T7,T12	T2,T4 T8,T10	T3,T5 T9,T11							