


## WYE - DELTA STARTING USEABLE ON 2, 4 AND 6 POLE MOTORS.



REFER TO THE WYE-DELTA STARTER CONNECTION INSTRUCTIONS FOR PROPER CONNECTION OF POWER LINES TO STARTER.



REFER TO THE CUTLER-HAMMER OR EQUIV. FOR PROPER SELECTION OF OVERLOAD HEATER COILS.



ACROSS THE LINE START & RUN										
	LINE 1	LINE 2	LINE 3	JOIN & INSULATE SEPARATELY						
HIGH VOLT	T1,T12	T2,T10	T3,T11	(T4,T7) (T5,T8) (T6,T9)						
LOW VOLT	T1,T6 T7,T12	T2,T4 T8,T10	T3,T5 T9,T11							

• RED LEADS OR P1, P2, FOR N/C THERMOSTAT

									·					
				TOI UNLES	ERANCES S SPECIFIED					DRAWN RJW 07-19-2007				
				DEC.	INCHES			<u> </u>	<u> </u>		СНК	ML 07-19-	-2007	
				.x	±.1				3 LLL	兲		APPD	GK 07-19-	-2007
				.xx	±.02	TITLE DELTA - WYE CONNECTION DI			ON DIA	GRA	M	SCALE	1=1	
				.xxx	±.005							REF	REF MU61151	
				.xxxx	±.0005	MAT'L.					FMF			
NO.	NO. REVISION BY & DATE				±7'30"	FINISH					PREV			
THIS DRAWING IN DESIGN AND DETAIL IS OUR PROPERTY AND MUST NOT BE USED EXCEPT IN CONNECTION WITH OUR WORK ALL RIGHTS OF DESIGN AND INVENTION ARE RESERVED THIS IS AN ELECTRONICALLY GENERATED DOCUMENT — DO NOT SCALE THIS PRINT			RFP 07-19-2007 CAD FILE 00			4172-01ME		,	SIZE	DRAWING NO			REV.	
			DIST_LB					A   004172-			1ME			